


BARBOY

Design by VERNER PANTON

1



Recommendation:

If the furniture is placed on a soft surface (wooden floor, linoleum etc.) it is recommended to keep the protective cover on the wheels to avoid scratching the floor surface.

Maintenance of Barboy


Wipe off with a damp cloth. Grease stains can be removed with soapy water. Don't use abrasive an cloth or substances as it will scratch the painted surface.

If the cassettes move too easily they can be strengthened by tightening the metal handle on the top of the Barboy (see drawing no. 3)

Slight tolerance in diameter of cylinder may occur.

For indoor use only!


2



Handle: must be tightened periodically.

Barboy has fulfilled the requirements in EN 14749:2005 Domestic and kitchen storage units and worktops. The test has been performed by DANISH TECHNOLOGICAL INSTITUTE.

If boxes are overloaded draws can hang. Please be aware of recommended max. weight in the following positions (no. 4 and 5). The stated max. recommended weight is based on the identity of the opposite unit(s) are empty.



IMPORTANT!

Screws should only be tightened/ loosened when using a screwdriver with rubber surface; but we recommend not to screw the screws, as you may scratch the surface and the painting can fall of!

Using a metal screwdriver can scratch the surface and the painting can fall of!

If a metal screwdriver is used, it is not justified complaints.

The diagram shows a kitchen unit with four screws on its front panel. A circular callout with a red 'X' over a screwdriver icon points to one of the screws, indicating that a metal screwdriver should not be used.

DESIGNED
IN THE PAST
MADE FOR
TOMORROW

VERPAN ApS
Egeskovvej 29
8700 Horsens
Denmark

www.verpan.com

info@verpan.dk