


SIORA


User manual




2D (two directions) adjustable armrests
3D (three directions) adjustable armrests



Seat height adjustment 110 mm




Backrest locking in 5 positions




Tilt tension adjustment






Forward tilt




60 mm
run range


Seat depth adjustment



70 mm
run range

Height-adjustable lumbar support






2D and 3D
adjustable
armrests

Height adjustment at the armrest carrier



100 mm
run range




2D, 3D
adjustable
armrests

Width adjustment via the armrest lever



65 mm
run range




3D adjustable
armrests

Pad adjustment forward and backward



50 mm
run range



for soft floor



for hard floor

Self-braking castors

Note. Self-braking chair castors activate the integrated friction brake and stop moving when the chair is unused (no weight applied to the seat).

Other documents available for this product

Technical information for SILORA task chairs
 Environmental product profile
 NARBUTAS product care guide